

			4014 SHOCKS & Pro Line springs								
Motorbrand and Type	Bike Factory code	Model year	Twin	Shock	SPIN	FUSION	EMULSION	P _{preload} A _{adjuster} = option	length WP shock	ProLine Spring	ProLine set up data
APRILIA											
Caponord ETV 1000	ZD4/PS	01>				17.01.V8.08/01	17.01.V9.08/01	✓	361-371	9932.0279.A	Oil: SAE 20(2Ltr) Air chamber:150MM Spacer: sTD
MOTO 6.5	MH00	96>								9932.0102.B	Oil: SAE 7.5 Air chamber: 135 MM
Pegaso 650 III (Marz.upsd)	ML	96>								9932.0091.B	Oil: SAE 15 Air chamber: 140 MM
RS 125 Extrema		93-05				17.01.N8.02	17.01.N9.02		276-286		
RS 125 SP		93-05				17.01.N8.02	17.01.N9.02		276-286		
RS 250 Race Replica (1 spring)	LD01	95-97								9932.0228.A	Oil: SAE 15 Air chamber: 200 MM
RSV 250 RACE	LDA1	98>								9932.0248.A	Oil: SAE 10 Air chamber: 100mm
RSV 1000 Mille	ZD4/2D4	99-00			17.01.T7.03		17.01.T9.03		321-331	9932.0272.B	Oil: SAE 5 Air chamber: 130 MM Spacer: 5 MM
RSV 1000 Mille		01>			17.01.X7.06		17.01.X9.06		316-326	9932.0272.B	Oil: SAE 5 Air chamber: 130 MM Spacer: 5 MM
SL 1000 Falco	PA	99>			17.01.T7.04/01		17.01.T9.04/01	✓	313-323	9932.0272.A	Oil: SAE 5 Air chamber: 130 MM Spacer H=5
Tuono 1000		06>			17.01.7B.09/01		17.01.9B.09/01	✓	307-317	9932.0246.B	Oil SAE5 Air chamber:145MM
BIMOTA											
DB 2	DB2									9932.0187.H	Oil : SAE 15 Air chamber: 150 MM Spacer H=75
DIECE YP8	YB8	91>								9602.0006.A	Oil: SAE 7.5 Air chamber: 160 MM Spacer: 10 MM
BMW											
C1	192A	02-03	♦♦				17.06.W9.01		366-376		
F650	169	94>				17.06.O8.02/01	17.06.O9.02/01		315-325	9932.0205.A	Oil: SAE 10 Air chamber: 140 MM
F650 Strada	163	97-01								9932.0205.B	Oil: SAE 10 Air chamber: 130 MM Spacer H=10
F650 GS	R13	00>				17.06.U8.06/01	17.06.U9.06/01	✓	316-326	9932.0115.B	Oil: SAE 15 Air chamber: 140 MM
F650 GS Dakar	R13	00>				17.06.U8.08/01	17.06.U9.08/01	✓	326-336	9932.0115.C	Oil: SAE 15 Air chamber: 140 MM Spacer H=100
F650 CS	174	02>				17.06.W8.04	17.06.W9.04		300-310	9932.0115.D	Oil: SAE 15 Air chamber: 180 MM Spacer:35mm
F800 / S		06>				17.06.8B.82/01	17.06.9B.82/01	✓	342-352	9932.0308.A	Oil: SAE 7.5 Air chamber: 130 MM
F800 / S lowered bike version		06>				17.06.8B.83/01	17.06.9B.83/01	✓	331-341	9932.0308.A	Oil: SAE 7.5 Air chamber: 130 MM
F800 GS		08				17.06.8D.87/01	17.06.9D.87/01	✓	424-434	9932.0308.A	Oil: SAE 7.5 Air chamber: 130 MM
G450X		08								Q3 2008	
G650Xmoto		08								Q3 2008	
G650Xchallenge		08								Q3 2008	
G650Xcountry		08								Q3 2008	
HPiI Enduro		05>								9931.0051.A	Oil: SAE 7.5 Air chamber:95 MM
HPiI Street		05>								9932.0311.A	Oil: SAE 7.5 Air chamber:95 MM
HPiI Supermotard		05>								9932.0312.A	Oil: SAE 7.5 Air chamber:95 MM
K 75 C	75C	86>			17.06.E7.22/01		17.06.E9.22/01	✓	356-366	9932.0220.B	Oil: SAE 10 Air chamber: 170 MM Spacer H=30
K 75 RT	75	83-91			17.06.E7.22/01		17.06.E9.22/01	✓	356-366	9932.0116.A	Replaced by: 9932.0220.B
K 75 RT/S	75	90-91			17.06.E7.22/01		17.06.E9.22/01	✓	356-366	9932.0108.A	Oil: SAE 15 Air chamber: 170 MM

K 75 RT/S (Showa 41 mm)	75	92>		17.06.E7.22/01		17.06.E9.22/01	✓	356-366	9932.0093.D	Oil: SAE 15 Air chamber: 170 MM Spacer H=20
K 75 S	75	83>				17.06.E9.21		343	9932.0116.A	Replaced by: 9932.0220.B
K1	100	89-90		17.06.J7.10		17.06.J9.10		383-393	9932.0073.A	Oil: SAE 5 Air chamber: 150 MM afstandbus:d19xd31x18
K1 (Cartridge Frontfork)	100	91>		17.06.J7.10		17.06.J9.10		383-393	9932.0192.B	Oil: SAE 10 Air chamber: 160 MM Spacer: 15 MM
K1 (ABS)	100	89-90				17.06.J9.10		383-393	9932.0073.A	Oil: SAE 5 Air chamber: 150 MM afstandbus:d19xd31x18
K1 (ABS)	100	91>				17.06.J9.10		383-393	9932.0192.B	Oil: SAE 10 Air chamber: 160 MM Spacer: 15 MM
K100	100	83>		17.06.E7.22/01		17.06.E9.22/01		356-366	9932.0220.C	Oil : SAE 10 Air chamber: 170 MM Spacer: 30 MM
K100 LT/RT	100	83>		17.06.E7.22/01		17.06.E9.22/01		356-366	9932.0108.C	Oil: SAE 15 Air chamber: 170 MM
K100 RS 16 Valve	100	90>		17.06.K7.12/01		17.06.K9.12/01	✓	377-387	9932.0192.C	Oil: SAE 7.5 Air chamber: 140 MM Afstandbus: d19xd31x18
K100 RS	100	83-89		17.06.E7.22/01		17.06.E9.22/01		356-366	9932.0108.B	Oil: SAE 15 Air chamber: 170 MM
K100 L348 (ALL MOD)	75/100	83>							9932.0116.A	Replaced by: 9932.0220.B
K1100 LT	100	92>		17.06.K7.12/01		17.06.K9.12/01		377-387	9932.0192.A	Oil: SAE 10 Air chamber: 160 MM Spacer:15 MM
K1200R (REAR)		05>			17.06.8A.78/01			331-341		
K1200R (FRONT)		05>				17.06.9A.79/01		318-328		
K1100 RS	100	92-95		17.06.N7.14		17.06.N9.14		380-390	9932.0192.A	Oil: SAE 10 Air chamber: 160 MM Spacer:15 MM
K1200 S (REAR)		05>			17.06.8A.76/01	17.06.9A.76 -only /02	✓	331-341		
K1200 S (FRONT)		05>				17.06.9A.77/01		318-328		
K1200 R (REAR)		05>			17.06.8A.78/01		✓	331-341		
K1200 R (FRONT)		05>				17.06.9A.79/01		318-328		
K1200 RS (REAR)	589	97>			17.06.R8.18/01	17.06.R9.18/01	✓	354-364		
K1200 RS (FRONT)	589	97>				17.06.R9.20		314-324		
K1200 LT (REAR)	105	99-03				17.06.U9.16/01	✓	398-408		
K1200 LT (FRONT)	105	99-03								
K1200 LT (REAR)		04>							Q1 2009	
K1200 LT (FRONT)		04>							Q1 2009	
K1200 GT (REAR)	WB105	03>			17.06.X8.72/01	17.06.X9.72/01	✓	351-361		
K1200 GT (FRONT)	WB105	03>				17.06.X9.73		313-323		
R 45 N	248A	78-85	◆◆						9932.0017.B	Oil: SAE 10 Air chamber: 120 MM Spacer H=15
R 50		87<	◆◆			17.06.A9.55		335-345	9932.0023.A	Oil: SAE 10 Air chamber: 150 MM
R 60		87<	◆◆			17.06.A9.55		335-345	9932.0023.A	Oil: SAE 10 Air chamber: 150 MM
R 75		87<	◆◆			17.06.A9.55		335-345	9932.0023.A	Oil: SAE 10 Air chamber: 150 MM
R 80		87<	◆◆			17.06.A9.55		335-345	9932.0023.A	Oil: SAE 10 Air chamber: 150 MM
R 90		87<	◆◆			17.06.A9.55		335-345	9932.0023.A	Oil: SAE 10 Air chamber: 150 MM
R 100		87<	◆◆			17.06.A9.55		335-345	9932.0023.A	Oil: SAE 10 Air chamber: 150 MM
R 65 G/S	248	87<		17.06.D7.61/01		17.06.D9.61/01		361-371	9932.0023.B	Oil: SAE 7.5 Air chamber: 170 MM
R65 (Einarm)	248	85>			17.06.F8.59	17.06.F9.59		412-422	9932.0069.C	Oil: SAE 10 Air chamber: 140 MM
R80 (Einarm)	248	85>			17.06.F8.59	17.06.F9.59		412-422	9932.0069.C	Oil: SAE 10 Air chamber: 140 MM
R 65 RT (Einarm)	248	85>			17.06.F8.59	17.06.F9.59		412-422	9932.0070.A	Oil: SAE 10 Air chamber: 140 MM
R 75	5	71>							9932.0212.H	Oil : SAE 10 Air chamber: 140 MM Spacer H=30

R 80 G/S	247E	87<		17.06.D7.61/01		17.06.D9.61/01		361-371	9932.0023.B	Oil: SAE 7.5 Air chamber: 170 MM
R 80 G/S Spec.Rally	247E	87<		17.06.D7.57		17.06.D9.57		360	9932.0023.B	Oil: SAE 7.5 Air chamber: 170 MM
R 80 RS/RT (Einarm)	247E	85>			17.06.F8.59	17.06.F9.59		412-422	9932.0070.A	Oil: SAE 10 Air chamber: 140 MM
R 100 RS/RT (Einarm)	247E	85>			17.06.F8.59	17.06.F9.59		412-422	9932.0070.A	Oil: SAE 10 Air chamber: 140 MM
R 80 ST	247E	83>		17.06.D7.71		17.06.D9.71		345-355	9932.0017.B	Oil: SAE 10 Air chamber: 120 MM Spacer H=15
R 80 GS Paris Dakar HARD	247E	88>		17.06.M7.64/01		17.06.M9.64/01	✓	490-500	9932.0188.A	Oil: SAE 7.5 Air chamber: 160 MM
R 100 GS Paris Dakar HARD	247E	88>		17.06.M7.64/01		17.06.M9.64/01	✓	490-500	9932.0188.A	Oil: SAE 7.5 Air chamber: 160 MM
R 80 GS Paralever	247E	88-91		17.06.M7.64/01		17.06.M9.64/01	✓	490-500	9932.0102.A	Oil: SAE 7.5 Air chamber: 160 MM
R 100 GS Paralever	247E	88-91		17.06.M7.64/01		17.06.M9.64/01	✓	490-500	9932.0102.A	Oil: SAE 7.5 Air chamber: 160 MM
R 80 R Paralever	247E	92>		17.06.M7.24		17.06.M9.24		468-478	9932.0162.A	Oil: SAE 10 Air chamber: 170 MM
R 100 R Paralever	247E	92>		17.06.M7.24		17.06.M9.24		468-478	9932.0162.A	Oil: SAE 10 Air chamber: 170 MM
R100 GS PARIS DAKAR		89>							9932.0103.A	Oil: SAE BMW Air chamber: AG. MM
R100 +RT/RS		88>							9932.0069.A	Oil: SAE 10 Air chamber: 140 MM
R 850 R/RS (REAR)	259	93>			17.06.P8.67/01	17.06.P9.67/01		356-366		
R 1100 R/RS (REAR)	259	93>				17.06.P8.67/01		356-366		
R 850 R/RS (FRONT)	259	93>			17.06.P7.65			319		
R 1100 R/RS (FRONT)	259	93>			17.06.P7.65			319		
R1100 S (REAR)	WB104	99-05			17.06.T7.33/01			✓	308-318	
R1100 S (FRONT)	WB104	99-05			17.06.T7.34				316-326	
R1100 GS (REAR)	259	94>				17.06.O8.27/01		✓	379-389	
R1100 GS (FRONT)	259	94>			17.06.O7.29				334	
R1100 RT (REAR)	259	95>				17.06.P8.67/01		✓	356-366	
R1100 RT (FRONT)	259	95>			17.06.P7.31				327-337	
R1150 GS (FRONT)		99>							334	
R1150 GS (REAR)		99>				17.06.T9.37		✓	385-395	
R1150GS Adv. FRONT	R21	02-05			17.06.W7.38				341	
R1150GS Adv. REAR	R21	02-05				17.06.W8.39/01		✓	389-399	
R1150 R (FRONT)	104	01>			17.06.V7.44				325	
R1150 R (REAR)	104	01>				17.06.V8.42/01		✓	362-372	
R1200R (FRONT)		07>			17.06.7C.87				320-330	
R1200R (REAR)		07>			17.06.7C.88/01			✓	375-385	
R1150 RS (FRONT)		02>			17.06.W7.48				316	
R1150 RS (REAR)		02>				17.06.W8.46/01		✓	362-372	
R1150 RT (FRONT)		01>			17.06.V7.52				330	
R1150 RT (REAR)		01>				17.06.V8.50/01		✓	362-372	
R1200 C (REAR)	259C	98>			17.06.S7.54				325-335	
R1200 C (FRONT)	259C	98>							320-330	
R1200 GS (REAR)		407			17.06.Y7.69/01			✓	399-409	
R1200 GS (FRONT)		407			17.06.Y7.70				336-346	

R1200 GS (REAR)		08>		17.06.Y7.69/01		17.06.Y9.69/01	✓	399-409		
R1200 GS (FRONT)		08>		17.06.Y7.70		17.06.Y9.70		336-346		
R1200GS Adv. FRONT	WB1038	06>		17.06.7B.86				350		
R1200GS Adv. REAR	WB1038	06>			17.06.W8.39/01	17.06.W9.39/01	✓	389-399		
R1200 S (REAR)	WB103	06>		17.06.7B.84/01		17.06.9B.84/01	✓	355-365		
R1200 S (FRONT)	WB103	06>		17.06.7B.85		17.06.9B.85		291-301		
R1200R Rear		07>		17.06.7C.88		17.06.9C.88		375-385		
R1200R FRONT		07>		17.06.7C.87		17.06.9C.87		320-330		
BUELL										
LIGHTNING XB9S	XB1	05>			17.49.Y8.01	17.49.Y9.01		357-367	9932.0199.D	Oil: SAE 5 Air chamber: 135 MM Spacer H=55
LIGHTNING XB12S	XB1	05>			17.49.Y8.01	17.49.Y9.01		357-367	9932.0199.D	Oil: SAE 5 Air chamber: 135 MM Spacer H=55
FIREBOLT XB9R	XB1	05>			17.49.Y8.01	17.49.Y9.01		357-367	9932.0199.D	Oil: SAE 5 Air chamber: 135 MM Spacer H=55
FIREBOLT XB12R	XB1	05>			17.49.Y8.01	17.49.Y9.01		357-367	9932.0199.D	Oil: SAE 5 Air chamber: 135 MM Spacer H=55
ULYSSES XB12X	DX03	06>			17.49.8B.02/01	17.49.9B.02/01	✓	372-382	9932.0314.A	Oil: SAE 15 Air chamber:130 MM
ULYSSES XB12X LOW	DX03	06>			17.49.8B.03/01	17.49.9B.03/01	✓	351-361	9932.0314.A	Oil: SAE 15 Air chamber:130 MM
CAGIVA										
RAPTOR 1000	M2	00>							9932.0219.B	Oil: SAE 20 Air chamber: 95 MM
125 FRECCIA	5PE	89>							9932.0039.A	Oil: SAE 15 Air chamber: 150 MM
DUCATI										
400 SS (Showa)		91-94							9932.0126.F	Oil: SAE 5 Air chamber: 130 MM
600 SS (Marz.UPSD)	S	94>				17.09.P9.01/01		328-338	9931.0017.A	Oil: SAE 5 Air chamber: 110 MM
748/SP (Showa UPSD)	ZDM748S	94-99				17.09.P9.02		311-321	9932.0219.A	Oil: SAE 7.5 Air chamber: 130 MM
748/SP (Showa UPSD)	ZDM748S	94-99				17.09.P9.02		311-321	9932.0219.A	Oil: SAE 7.5 Air chamber: 130 MM
748/ S/ R		2		17.09.U7.03/01		17.09.U9.03	✓	301-311		
749 S		03>		17.09.X7.04		17.09.X9.04		301-311	9932.0219.C	Oil: SAE 7.5 Air chamber: 130 MM
750 Sport		88-90							9932.0106.F	Oil: SAE 7.5 Air chamber: 150 MM Spacer H=40
750 SS (Showa UPSD)	ZDM750SC	91-94		17.09.L7.05/01		17.09.L9.05/01	✓	327-337	9932.0126.C	Oil: SAE 5 Air chamber: 130 MM
750 SS (Marz. UPSD)	ZDM750SC	95>				17.09.P9.01/01	✓	327-337	9602.0003.B	Oil: SAE 5 Air chamber: 110 MM
851 Strada (Marz.42M1R)	ZDM851S1	88-89							9932.0082.B	Oil: SAE 5 Air chamber: 140 MM
851 Strada (Showa UPSD)	ZDM851S3	90-92							9932.0187.F	Oil: SAE 10 Air chamber: 130 MM Spacer H=30
888 SP5 /Superbike (Ohlins)	ZDM888S1	91>							9932.0187.G	Oil : SAE 10 Air chamber: 130 MM Spacer H=30
888 Strada (Showa UPSD)	ZDM888S	93>							9932.0187.G	Oil : SAE 10 Air chamber: 130 MM Spacer H=30
900 SS	ZDM900S	88<							9932.0003.A	Oil: SAE 15 Air chamber: 140 MM
900 SS	ZDM906SC	89-90							9932.0106.E	Oil: SAE 5 Air chamber: 130 MM Spacer H=40
900 SS	ZDM906C2	91-95							9932.0187.C	Oil: SAE 10 Air chamber: 130 MM Spacer H=15
900 SS	ZDMV100	96-97		17.09.P7.07		17.09.P9.07		338-348	9932.0126.H	Oil: SAE 5 Air chamber: 130 MM
900 SS	ZDMV100	98>		17.09.S7.09		17.09.S9.09		335-345	9932.0276.A	Oil: SAE 10 Air chamber: 120 MM
907 Paso I.E.	ZDM906PI2	92>							9932.0155.B	Oil: SAE 15 Air chamber: 150 MM Spacer: 15mm
916 Strada (Showa UPSD)	ZDM916S	94-99				17.09.P9.02		311-321	9932.0219.A	Oil: SAE 7.5 Air chamber: 130 MM

996 SPS		2		17.09.U7.10		17.09.U9.10		301-311		
999 S		03>		17.09.X7.11		17.09.X9.11		301-311	9932.0219.C	Oil: SAE 7.5 Air chamber: 130 MM
M 600 (Showa/Marz. UPSD)	ZDM600	94>		17.09.N8.12/01	17.09.N9.12/01	✓		331-341	9602.0005.C	Oil: SAE 5 Air chamber: 130 MM
M 750 (Showa UPSD)	ZDMM100	95-96		17.09.N8.12/01	17.09.N9.12/01	✓		331-341	9932.0126.G	Oil: SAE 5 Air chamber: 130 MM
M 750 (Marz.UPSD)	M100AA	97>		17.09.N8.12/01	17.09.N9.12/01	✓		331-341	9602.0005.D	Oil: SAE 5 Air chamber: 130 MM
M 900 (Showa UPSD)	ZDM900M	93-96		17.09.N8.12/01	17.09.N9.12/01	✓		331-341	9932.0126.C	Oil: SAE 5 Air chamber: 130 MM
M 900 (Marz. UPSD)	ZDM900M	97>		17.09.N8.12/01	17.09.N9.12/01	✓		331-341		
916 Monster S4	ZDMM460	01>		17.09.V8.16	17.09.V9.16			305-315		
ST-4	S200AA	99>		17.09.T8.14/01	17.09.T9.14/01	✓		306		
HARLEY-DAVIDSON										
11.5"			◆◆	17.48.J7.01		17.48.J9.01		295		
12.5"			◆◆	17.48.J7.02		17.48.J9.02		320		
13.0"			◆◆	17.48.J7.06		17.48.J9.06		331		
13.5"			◆◆	17.48.J7.03		17.48.J9.03		340		
14.25"			◆◆	17.48.J7.04		17.48.J9.04		359-369		
15.0"			◆◆	17.48.J7.05		17.48.J9.05		378-388		
XL 1200			◆◆	17.48.7D.13		17.48.9D.13				
XLH 883 HUGGER	XL/2	88-91	◆◆						9932.0074C	
XLH 883 SPORTSTER	XL/2	88>	◆◆						9932.0074C	
XLH 1200 SPORTSTER	XL/2	88-94	◆◆						9932.0074C	
XR 1200			◆◆	17.48.7D.13		17.48.9D.13				
883R Sport Cup			◆◆						9932.0069.B	Oil: SAE 15 Air chamber: 140 MM Spacer H=25
V-ROD VRSCA/B	HBZ17	04>	◆◆	17.48.Y7.11		17.48.Y9.11		325-335	9932.0268.B	Oil: SAE 10 Air chamber: 90 MM Spacer H=100
STREET-ROD VRSCR		05>	◆◆	17.48.7A.12		17.48.9A.12		395-405		
HONDA										
CB 250 (Japan)	CB250T	93>							9932.0236.A	Oil: SAE 10 Air chamber: 140 MM
CB 400 N	CB400T	78>							9932.0003.D	Oil : SAE 10 Air chamber: 140 MM Spacer H=15
CB 400 Super Four	NC31	92>	◆◆	17.14.M7.07		17.14.M9.07		326-336	9932.0172.A	Oil: SAE 15 Air chamber: 110 MM
CB-1	NC27	89>		17.14.K8.17	17.14.K9.17			309-319	9932.0137.B	Oil: SAE 7.5 Air chamber: 140 MM Spacer: 10
CB 400 F	NC27	89>		17.14.K8.17	17.14.K9.17			309-319	9932.0137.B	Oil: SAE 7.5 Air chamber: 140 MM Spacer: 10
CB 450 N/S	PC14/17	85>							9932.0043.A	Oil: SAE 10 Air chamber: 150 MM
CB 500 S	PC26/32	93-99	◆◆			17.14.O9.04		348	9932.0198.A	Oil: SAE 7.5 Air chamber: 160 MM
CB 500 S		00>	◆◆	17.14.U7.08		17.14.U9.08		378-388		
CB 550 F 1/2 Four in One	CB550F	76-77							9932.0008.A	Oil: SAE 10 Air chamber: 160 MM
CB 550 K3	CB550K	78>							9932.0008.E	Oil: SAE 15 Air chamber: 140 MM
CB 600 F Hornet	PC34	98-02		17.14.S8.09	17.14.S9.09			299-309	9932.0251.A	Oil: SAE 15 Air chamber: 125 MM
CB 600 SF Hornet	PC 36	03-04		17.14.S8.09	17.14.S9.09			299-309	9932.0250.D	Oil: SAE 15 Air chamber: 120 MM Spacer 75 MM
CB 600 SF Hornet	PC 36A	05-06		17.14.8A.98	17.14.9A.98			297-307	9932.0294.B	Oil: SAE 10 Air chamber: 80 MM
CB 600 SF Hornet		07>		17.14.8C.03	17.14.9C.03			301-311	Q42008	

CB 1000		07>						Q3 2008	
CB 650 A/B	RC03	81>						9932.0013.A	Oil: SAE 10 / Air chamber: 150 MM
CB 750 Custom								9932.0008.H	Oil: SAE 15 / Air chamber: 160 MM / Spacer H=75
CB 750 F1 Four in One	CB750F	77-78	◆◆					9932.0008.G	Oil: SAE 10 / Air chamber: 130 MM / Spacer H=10
CB 750 FB	RC04	81>	◆◆					9932.0013.C	Oil: SAE 15 / Air chamber: 140 MM
CB 750 K0-K7	CB750K	71>						9932.0008.B	Oil: SAE 10 / Air chamber: 160 MM
CB 750 KZ	RC01	79>						9932.0013.B	Oil: SAE 15 / Air chamber: 150 MM
CB 750 Seven Fifty	RC42	93>	◆◆	17.14.N7.12		17.14.N9.12	358	9932.0244.C	Oil: SAE 15 / Air chamber: 150 MM / Spacer H=25
CB 750 Nighthawk								9932.0093.F	Oil: SAE 15 / Air chamber: 160 MM / Spacer: Li 95/Re 45
CB 900 FA Bold'Or (DU=35)	SC01	80	◆◆	17.14.D7.15		17.14.D9.15	363-373	9932.0012.A	Oil: SAE 15 / Air chamber: 130 MM
CB 900 FB Bold'Or (DU=37)	SC01	81	◆◆	17.14.D7.15		17.14.D9.15	363-373	9932.0035.A	Oil: SAE 15 / Air chamber: 140 MM
CB 900 FC Bold'Or (DU=39)	SC09	82	◆◆	17.14.D7.15		17.14.D9.15	363-373	9932.0078.A	Oil: SAE 10 / Air chamber: 140 MM
CB 900 F	SC48	02>			17.14.W8.13	17.14.W9.13	281-291	9932.0284.A	Oil: SAE 10 / Air chamber: 130 MM
CB 1000 Super Four	SC30	92>	◆◆	17.14.M7.05		17.14.M9.05	352-362	9932.0191.A	Oil: SAE 15 / Air chamber: 170 MM
CB 1000 R		08						Q3 2008	
CB 1100 F		85>						9932.0083.B	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=10
CB 1100 RD	SC08	83>						9932.0093.E	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=20
CB 1300 link version	SC40	98>	◆◆	17.14.S7.06		17.14.S9.06	308-318	9932.0256.A	Oil: SAE 10 / Air chamber: 169 MM
CB 1300	SC54	03>	◆◆					Q1 2009	
CBF 600	PC 38	04>			17.14.Y8.99	17.14.Y9.99	288-298	9932.0250.E	Oil: SAE 20 / Air chamber: 140 MM / Spacer H=100
CBF 600 SA		08						Q5 2008	
CBF 600 NA		08						Q5 2008	
CBF 1000		06>			17.14.8B.01	17.14.9B.01		9932.0211.C	
CBR 400 RR	NC23	89-91						9932.0229.C	Oil: SAE 10 / Air chamber: 160 MM / Spacer H=5
CBR 400 RR	NC29	92>			17.14.J8.23		290-300	9932.0128.C	Oil: SAE 7.5 / Air chamber: 140 MM / Spacer H=55
CBR 600 F/R Hurricane	PC19/23	87-90			17.14.H8.30	17.14.H9.30	291-301	9932.0071.A	Oil: SAE 15 / Air chamber: 140 MM
CBR 600 F	PC25	91-92		17.14.N7.26		17.14.N9.26	293-303		Oil: SAE 7.5 / Air chamber: 130 MM / Spacer H=15
CBR 600 F	PC25	93-94		17.14.N7.26		17.14.N9.26	293-303	9932.0139.A	Oil: SAE 7.5 / Air chamber: 150 MM
CBR 600 F	PC31	95-96			17.14.P8.27	17.14.P9.27	283-293	9932.0229.D	Oil: SAE 5 / Air chamber: 150 MM / Spacer H=25
CBR 600 F	PC31	97-98			17.14.P8.27	17.14.P9.27	283-293	9602.0020.C	Oil: SAE 5 / Air chamber: 140 MM / Spacer H=50
CBR 600 F	PC35	99-00		17.14.T7.29/01		17.14.T9.29/01	307-317	9932.0259.A	Oil: SAE 5 / Air chamber: 135 MM
CBR 600 F		01-02		17.14.V7.24/01		17.14.V9.24/01	277		
CBR 600		07>		17.14.7C.02		17.14.9C.02	290-300		
CBR 600 RR	PC37	03-04			17.14.X8.31/01	17.14.X9.31	302-312	9932.0296.A	Oil: SAE 10 / Air chamber: 115 MM
CBR 600 RR	PC37A	05-06						Q5 2008	
CBR 600 RR		07>		17.14.7C.02/01		17.14.9C.02/01	290-300		
CBR 900 RR Fireblade		92-93						9932.0193.A	Oil: SAE 7.5 / Air chamber: 160 MM
CBR 900 RR Fireblade	SC33	96-97		17.14.Q7.37		17.14.Q9.37	304-314	9932.0193.C	Oil: SAE 7.5 / Air chamber: 160 MM / Spacer H=40
CBR 900 RR Fireblade	SC33	98-99		17.14.S7.34		17.14.S9.34	303-313	9932.0193.B	Oil: SAE 7.5 / Air chamber: 140 MM / Spacer H=45

CBR 900 RR Fireblade	SC44	00-01			17.14.U8.32	17.14.U9.32		280-290	9932.0265.A	Oil: SAE 10 / Air chamber: 100 MM
CBR 900 RR 2 Fireblade	SC50	02-03		17.14.W7.33		17.14.W9.33		280-290	9932.0234.B	Oil: SAE 5 / Air chamber: 80 MM / Spacer H=90
CBR 1000 F/R HUR.	SC21	87-90			17.14.H8.19/01	17.14.H9.19/01		298-308	9932.0130.A	Oil: SAE 10 / Air chamber: 170 MM
CBR 1000 F	SC24	89-92			17.14.H8.19/01	17.14.H9.19/01		298-308	9932.0174.A	Oil: SAE 10 / Air chamber: 150 MM
CBR 1000 F (Dual Brakesystem)	SC24	93>			17.14.H8.19/01	17.14.H9.19/01		298-308	9932.0201.A	Oil: SAE 10 / Air chamber: 150 MM
CB 1000 R		08>			17.14.8D.02	17.14.9D.02		301-311		
CBR 1000 RR Fireblade		04>		17.14.Y7.95/01		17.14.Y9.95/01	✓	316-326	Q5 2008	
CBR 1000 RR Fireblade		08>							Q3 2008	
CBR 1100 XX Super- Blackbird	SC35	97>			17.14.R8.21/01	17.14.R9.21/01	✓	322-332	99320282.A	
CBX 550 F/F2	PC04	82>				17.14.A9.39		268-278	9932.0044.A	Oil: SAE 10 / Air chamber: 150 MM
CBX 750 F	RC17	84>			17.14.E8.41	17.14.E9.41		305-315	9932.0084.A	Oil: SAE 10 / Air chamber: 140 MM
CBX (6-Cyl.) (DU=35)	CB1	79>	◆◆	17.14.D7.15		17.14.D9.15		363-373		
CBX 1000 C	SC06	81>				17.14.C9.40		286-296		
CX 500 E	PC06	83				17.14.G9.43		287-297	9932.0048.D	Oil: SAE 15 / Air chamber: 140 MM / Spacer H=5
CX 500 Z	CX500	79							9932.0001.A	Oil: SAE 15 / Air chamber: 140 MM
CX 500 B	CX500	81-82				17.14.G9.43		287-297	9932.0002.A	Oil: SAE 15 / Air chamber: 140 MM
CX 500 Turbo	PC03	83>				17.14.G9.43		287-297	9932.0055.K	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=65
CX 650 Turbo	RC16	83>				17.14.G9.43		287-297	9932.0055.K	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=65
GB 500 Clubman	PC16	89>							9932.0175.A	Oil: SAE 15 / Air chamber: 150 MM
GL 500 Silverwing	PC02	82>							9932.0008.F	Oil: SAE 15 / Air chamber: 140 MM
GL 650 D Silverwing	RC10	82>							9932.0008.F	Oil: SAE 15 / Air chamber: 140 MM
GL 1000 K1-K3 Goldwing	GL1/2	75-76							9932.0045.A	Oil: SAE 15 / Air chamber: 150 MM
GL 1100 Interstate	SC02	81>	◆◆						9932.0083.A	Oil: SAE 15 / Air chamber: 160 MM
GL 1200 DX	SC14	84>							9932.0115.A	Oil: SAE 15 / Air chamber: 160 MM
GL 1500 Goldwing	SC22	88-92							9932.0113.C	Oil: SAE 15 / Air chamber: 150 MM / Spacer H=40
GL 1500 Goldwing	SC22	93>				17.14.N9.44		339	9932.0113.C	Oil: SAE 15 / Air chamber: 150 MM / Spacer H=40
F6C	SC34	97>		17.14.R7.93/01		17.14.R9.93/01	✓	326	9932.0193.D	Oil: SAE 10 Oil chamber: 145mm Spacer: 25mm
NS 400 RF	NC19	85>							9932.0065.C	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=40
NT 600/650 Hawk-GT/Bros	RC31	88>				17.14.J9.45/01	✓	308-318	9932.0129.A	Oil: SAE 5 / Air chamber: 180 MM
NT 650V Deauville	RC47	98-05				17.14.S9.46/01	✓	301-311	9932.0128.F	Oil: SAE 7.5 / Air chamber: 140 MM / Spacer H=95
NT 700 V Deauville	RC52	06>							Q1 2008	
NTV 650 Revere	RC33	88>				17.14.J9.47/01	✓	296-306	9932.0137.A	Oil: SAE 5 / Air chamber: 180 MM
NX 250	MD21/25	88>				17.14.I9.48		320-330	9932.0079.A	Oil: SAE 15 / Air chamber: 130 MM
NX 650 Dominator	RD02	88-94				17.14.J9.49		343-353	9932.0135.A	Oil: SAE 7.5 / Air chamber: 140 MM
NX 650 Dominator	RD08	95>			17.14.P8.50	17.14.P9.50		371-381	9932.0130.G	Oil: SAE 10 / Air chamber: 160 MM / Spacer H=65
PC 800 Pacific Coast	RC34	88>	◆◆						9932.0201.B	Oil: SAE 10 / Air chamber: 150 MM / Spacer H=25
SLR 650	RD09	97>				17.14.R9.52		345-355		
ST 1100 Pan European	SC26	91-95				17.14.L9.53/01	✓	340-350	9932.0185.A	Oil: SAE 10 / Air chamber: 150 MM
ST 1100 Pan European (ABS)	SC26	91-95				17.14.L9.53/01	✓	340-350	9932.0203.A	Oil: SAE 10 / Air chamber: 170 MM

ST 1100 Pan European (MAJ)	SC26	96-98			17.14.T9.54		340-350	9932.0203.B	Oil: SAE 10 / Air chamber: 170 MM / Spacer H=10
ST 1100 Pan European	SC26	99-01			17.14.T9.54		340-350	9932.0203.C	Oil: SAE 10 / Air chamber: 170 MM / Spacer H=10
ST 1300 Pan European	SC51	02>		17.14.W8.90/01	17.14.W9.90/01	✓	326-336	9932.0270.B	Oil: SAE 10 / Air chamber: 95 MM / Spacer H=180
VF 700 C Magna	RC28	87						9932.0092.E	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=35
VF 700/750 F/Interceptor	RC15	83-84						9932.0097.A	Oil: SAE 10 / Air chamber: 140 MM
VF 750 C	RC09	82-84						9932.0058.D	Replaced by: 9932.0055.I
VF 750 C	RC09	92<						9932.0055.I	Oil: SAE 15 / Air chamber: 170 MM / Spacer H=50
VF 750 C	RC43	93>						9932.0130.D	Oil: SAE 7.5 / Air chamber: 140 MM / Spacer H=20
VF 1000 F/F2	SC15	84>			17.14.F9.58		405-415	9932.0118.A	Oil: SAE 10 / Air chamber: 150 MM
VF 1000 R	SC16	86>			17.14.F9.57/01	✓	400-410	9932.0118.A	Oil: SAE 10 / Air chamber: 150 MM
VF 1100 Sabre (V 65 S)								9932.0108.D	Oil: SAE 10 / Air chamber: 140 MM
VFR 400	NC21	87						9932.0074.E	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=5
VFR 400 R	NC30	89-91		17.14.J8.59	17.14.J9.59		303-313	9932.0128.E	Oil: SAE 7.5 / Air chamber: 130 MM / Spacer H=40
VFR 400 R (Frontfork.reb.adj.)	NC30	91>		17.14.J8.59	17.14.J9.59		303-313	9602.0005.B	Oil: SAE 10 / Air chamber: 150 MM / Spacer H=10
VFR 700 F	RC24	86-87			17.14.G9.62		269-279	9932.0072.A	Replaced by: 9932.0069.D
VFR 750 F	RC24	86-87			17.14.G9.62		269-279	9932.0072.A	Replaced by: 9932.0069.D
VFR 700 F	RC21	86-87						9932.0069.D	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=80
VFR 750 F	RC24	86-87						9932.0069.E	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=80
VFR 700 F	RC24	88-89			17.14.H9.61		278-288	9932.0220.G	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=60
VFR 750 F	RC24	88-89			17.14.H9.61		278-288	9932.0220.G	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=60
VFR 750 F	RC36	90-91		17.14.K8.63/01	17.14.K9.63/01	✓	347-357	9932.0113.A	Oil: SAE 5 / Air chamber: 170 MM
VFR 750 F	RC36	92-93		17.14.K8.63/01	17.14.K9.63/01	✓	347-357	9932.0128.D	Oil: SAE 10 / Air chamber: 170 MM / Spacer H=15
VFR 750 F	RC36	94-97		17.14.O8.65/01	17.14.O9.65/01	✓	320-330	9932.0213.A	Oil: SAE 10 / Air chamber: 170 MM
VFR 750 R	RC30	88>						9932.0148.A	Oil: SAE 5 / Air chamber: 125 MM
VFR 800 FI	RC42	98-01		17.14.S8.69/01	17.14.S9.69/01	✓	326-336	9932.0250.A	Oil: SAE 7.5 / Air chamber: 150 MM
VFR 800	RC46	02>		17.14.W8.67/01	17.14.W9.67/01	✓	314-324	9932.0286.A	Oil: SAE 7.5 / Air chamber: 110 MM
VT 500 E	PC11	83>						9932.0055.L	Oil: SAE 15 / Air chamber: 140 MM / Spacer H=65
VT 600 C Shadow	PC21	88>			17.14.I9.71		365-375	9932.0092.F	Oil: SAE 10 / Air chamber: 150 MM / Spacer H=60
VT 700 C	RC19	86>						9932.0097.C	Oil: SAE 10 / Air chamber: 140 MM
VT 750 C	RC44	97>						9932.0118.B	Oil: SAE 15 / Air chamber: 130 MM
VT 1100 Shadow	SC12	85-86						9932.0112.C	Oil: SAE 15 / Air chamber: 170 MM / Spacer H=10
VT 1100 Shadow	SC23/SC18	87>	◆◆					9932.0188.B	Oil: SAE 10 / Air chamber: 190 MM
VTR 1000 F Firestorm	SC36	97>		17.14.R8.72/01	17.14.R9.72/01	✓	347-357	9932.0252.A	Oil: SAE 10 / Air chamber: 150 MM
VTR 1000 SP I / II	SC45	00>		17.14.U7.74	17.14.U9.74		321-331	9932.0270.A	Oil: SAE 10 / Air chamber: 100 MM
XBR 500 (S)	PC15	85>						9932.0046.D	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=5
XL 250 RG	MD11	86>						9932.0034.A	Oil: SAE 10 / Air chamber: 180 MM
XL 500 R	PD02	82>						9931.0003.A	Oil: SAE 10 / Air chamber: 180 MM
XL 600 R/RD/RE	PD03	83-84						9931.0005.A	Oil: SAE 10 / Air chamber: 180 MM
XL 600 LM/RM	PD04	86>						9932.0134.A	Oil: SAE 10 / Air chamber: 180 MM

XL 600 V Transalp	PD06	87-88						9932.0132.A	Replaced by: 9932.0130.F
XL 600 V Transalp	PD06	89-93			17.14.J9.77		373-383	9932.0132.A	Replaced by: 9932.0130.F
XL 600 V Transalp	PD06	87-90			17.14.J9.77		373-383	9932.0130.F	Oil: SAE 10 / Air chamber: 160 MM / Spacer H=65
XL 600 V Transalp	PD06/10	94-99			17.14.J9.77		373-383	9932.0130.K	Oil: SAE 10 / Air chamber: 160 MM / Spacer H=40
XL 650 V Transalp	RD10A	00>		17.14.V7.80/01	17.14.V9.80/01	✓	313-323	9932.0130.H	Oil: SAE 10 / Air chamber: 160 MM / Spacer H=65
XL 700 VA Transalp		08>		17.17.8D.81/01	17.17.9D.81/01	✓		9932.0108.E	
XL 1000 V Varadero	YR19	99-02		17.14.T8.75/01	17.14.T9.75/01	✓	338-348	9932.0260.A	Oil: SAE 15 / Air chamber: 140 MM
XL 1000 V Varadero		03>		17.14.X8.91/01	17.14.X9.91/01	✓	330-340	9932.0260.C	Oil: SAE 10 / Air chamber: 115 MM / Spacer H=10
XR 250 R/RK	ME06	88-90						9932.0131.A	Oil: SAE 10 / Air chamber: 160 MM / Spacer H=10
XR 250 R		91-95						9601.0026.A	Oil: SAE 7.5 / Air chamber: 130 MM
XR 400 R		96>		17.14.Q7.81	17.14.Q9.81		392-402		
XR 600 RF/RG	PE04	85-86						9931.0010.B	Oil: SAE 10 / Air chamber: 170 MM
XR 600 RH	PE04	87						9931.0009.A	Oil: SAE 10 / Air chamber: 170 MM
XR 600 RJ	PE04	88						9931.0009.A	Oil: SAE 10 / Air chamber: 170 MM
XR 600 RK	PE04	89-90						9931.0009.A	Oil: SAE 10 / Air chamber: 170 MM
XR 600 R	PE04	91-93						9931.0015.A	Oil: SAE 10 / Air chamber: 130 MM
XR 600 R		94>		17.14.O7.82	17.14.O9.82		378-388	9931.0015.A	Oil: SAE 10 / Air chamber: 130 MM
XRV 650 Africa Twin	RD03	88-92		17.14.J8.84/01	17.14.J9.84/01	✓	372-382	9932.0167.C	Oil: SAE 7.5 / Air chamber: 160 MM / Spacer H=15
XRV 750 Africa Twin	RD04	88-92		17.14.J8.84/01	17.14.J9.84/01	✓	372-382	9932.0167.C	Oil: SAE 7.5 / Air chamber: 160 MM / Spacer H=15
XRV 750 Africa Twin	RD07	93>		17.14.N8.86/01	17.14.N9.86/01	✓	379-389	9932.0167.C	Oil: SAE 7.5 / Air chamber: 160 MM / Spacer H=15
X-4	SC38	97-99						9932.0230.K	Oil: SAE 15 / Air chamber: 140 MM / Spacer H=25
X-4	SC38	00>						9932.0230.L	Oil: SAE 15 / Air chamber: 140 MM
KAWASAKI									
ER-5	ER500	97>						9932.0074.B	Oil: SAE 5 / Air chamber: 190 MM / Spacer H=20
ER-6N / ER-6F	ER650AA	05>		17.17.7A.63	17.17.9A.63		288-298	9602.0007.B	Oil: SAE 15 / Air chamber: 120 MM
ER-6N / ER-6F LOW	ER650AA	05>		17.17.7A.64	17.17.9A.64		265-275	9602.0007.B	Oil: SAE 15 / Air chamber: 120 MM
GPX 600 R Warbird	ZX600C	88>						9932.0065.B	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=5
GPX 750 R	ZX750F	87>						9932.0074.D	Oil: SAE 7.5 / Air chamber: 140 MM / Spacer H=5
GPZ 500 S	EX500A	87-93			17.17.H9.03		309-319	9932.0046.A	Oil: SAE 10 / Air chamber: 150 MM
GPZ 550	ZX550A	81-83			17.17.B9.04		306-316	9932.0212.C	Oil: SAE 10 / Air chamber: 160 MM / Spacer H=5
GPZ 550	ZX550A	84>			17.17.C9.05		322	9932.0019.B	Replaced by: 9932.0212.C
GPZ 600 R Ninja	ZX600A	85>						9932.0065.A	Oil: SAE 10 / Air chamber: 140 MM
GPZ 750 Turbo	ZX750E	83>		17.17.D8.06	17.17.D9.06		306-316	9932.0037.A	Oil: SAE 15 / Air chamber: 150 MM
GPZ 900 RZ Ninja (D=38 mm)	ZX900A	84-86		17.17.E8.09	17.17.E9.09		313-323	9932.0056.A	Replaced by: 9932.0055.C
GPZ 900 R Ninja		84-89						9932.0055.C	Oil: SAE 10 / Air chamber: 150 MM / Spacer H=25
GPZ 900 RX Ninja (D=38 mm)	ZX900A	87-89		17.17.G8.07/01	17.17.G9.07/01	✓	313-323	9932.0056.A	Replaced by: 9932.0055.C
GPZ 900 R (D=41 mm)	ZX900A	90>		17.17.G8.07/01	17.17.G9.07/01	✓	313-323	9932.0129.B	Oil: SAE 7.5 / Air chamber: 130 MM
GPZ 1000 RX	ZXT00A	86>		17.17.G8.01	17.17.G9.01		313-323	9932.0091.A	Oil: SAE 10 / Air chamber: 150 MM
GPZ 1100 (ZX1100B1/ D34 mm)	KZT10B	82						9932.0046.E	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=5

GPZ 1100 (ZX1100B2)	KZT10B	83						9932.0055.J	Oil: SAE 15 / Air chamber: 150 MM / Spacer H=65
GPZ 1100 (Uni Track/D=32 mm)	KZT10B	83>			17.17.D8.02	17.17.D9.02		306-316 9932.0017.A	Oil: SAE 10 / Air chamber: 130 MM
GPZ 1100	ZX10TE	95>						9932.0201.C	Oil: SAE 7.5 / Air chamber: 130 MM / Spacer H=75
GTR 1000	ZGT00A	89>						9932.0093.B	Oil: SAE 10 / Air chamber: 150 MM
GTR 1400		08>			17.17.8D.00	17.17.9D.00		347-357	
KLE 500	LE500A	92>				17.17.M9.10		379-389 9932.0220.I	Oil: SAE 7.5 / Air chamber: 180 MM
KLR 250 R	KL250D	84>						9932.0059.A	Oil: SAE 7.5 / Air chamber: 180 MM
KLR 600 /E	KL600A/B	84>						9932.0061.A	Oil: SAE 10 / Air chamber: 180 MM
KLR 650 / Tengai	KL650A/B	87-94			17.17.H8.14	17.17.H9.14		400-410 9932.0061.B	Oil: SAE 10 / Air chamber: 160 MM
KLR 650	KL650C	95-07				17.17.P9.13		397-407	
KLX 650 C	LX650C	92>			17.17.N8.16	17.17.N9.16		446-456	Oil: SAE 10 / Air chamber: 100 MM
KLX 650 R	LX650A	92>		17.17.N7.18		17.17.N9.18		421-431 9932.0214.A	Oil: SAE 15 / Air chamber: 100 MM
KR-1S	KR250C2	90>						9932.0211.B	Oil: SAE 5 / Air chamber: 125 MM / Spacer H=80 or 100mm
KZ 1300 (6 Cyl.)	KZT00A	79>	◆◆					9932.0096.B	Replaced by: 9932.0092.D
Versys		07>			17.17.8C.68/01	17.17.9C.68/01	✓	295-305 9932.0229.E	
VN 800		95>						9932.0118.C	Oil: SAE 10 / Air chamber: 170 MM
VN 1500 Vulcan	VNT50A	87						9932.0220.F	Oil: SAE 10 / Air chamber: 160 MM / Spacer H=30
VN 1500 Vulcan	VNT50B/C/D	88>						9932.0117.B	Oil: SAE 10 / Air chamber: 180 MM
VN 1500	JKBVNAA	87-95						9932.0220.I	Oil: SAE 7.5 / Air chamber: 180 MM
W 650	J650A	99>						9932.0162.E	Oil: SAE 5 / Air chamber: 150 MM / Spacer H=45
Z 650 B	KZ650B/C	77-79						9932.0010.A	Oil: SAE 15 / Air chamber: 140 MM
Z 650 B	KZ650F	81>						9932.0212.F	Oil: SAE 15 / Air chamber: 150 MM / Spacer H=10
Z 750	KZ750	83<						9932.0007.B	replaced by 9932.0209.A
Z 750 (Japan)		83<						9932.0209.A	Oil: SAE 15 / Air chamber: 140 MM
Z 750		84>						9932.0212.G	Oil: SAE 15 / Air chamber: 140 MM / Spacer H=10
Z 750 (Japan)		84>						9932.0212.A	Oil: SAE 15 / Air chamber: 140 MM
Z 750	ZR750J	04>		17.17.Y7.62/01		17.17.Y9.62/01	✓	330-340 9932.0307.A	Oil: SAE 20 / Air chamber: 100 MM
Z 750		07>		17.17.7C.67/01		17.17.9C.67/01		330-340 9932.0307.A	Oil: SAE 20 / Air chamber: 100 MM
Z 1000 A1	KZT00A	78>	◆◆	17.17.H7.21		17.17.H9.21		350-360 9932.0008.C	Oil: SAE 10 / Air chamber: 140 MM
Z 1000 A2/Z-1 R	KZT00A	78>	◆◆	17.17.H7.21		17.17.H9.21		350-360 9932.0013.D	Oil: SAE 10 / Air chamber: 140 MM
Z 1000 J	KZT00J	81>	◆◆	17.17.H7.21		17.17.H9.21		350-360 9932.0046.B	Oil: SAE 10 / Air chamber: 140 MM
Z 1000 LTD	KZT00K	81>	◆◆	17.17.H7.21		17.17.H9.21		350-360	
Z 1000 MK2	KZT00A	79>	◆◆	17.17.H7.21		17.17.H9.21		350-360 9932.0013.E	Oil: SAE 15 / Air chamber: 140 MM
Z 1000 R (Lawson)	KZT00R	82>	◆◆	17.17.H7.21		17.17.H9.21		350-360 9932.0055.F	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=50
Z 1000 ST	KZT00E	79>						9932.0092.C	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=70
Z 1000	ZRT00	03>		17.17.X7.22/01		17.17.X9.22/01	✓	334-344 9932.0294.A	Oil: SAE 7.5 / Air chamber: 90 MM
Z 1000		07>						Q1 2009	
Z 1300	KZT30A/	79>						9932.0092.D	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=70
ZG 1200 Voyager USA		87						9932.0091.D	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=60

ZEPHYR 400 (Japan)	ZRX400C	91>							9932.0235.A	Oil: SAE 15 / Air chamber: 140 MM
ZEPHYR 550	ZR550B	92>	◆◆	17.17.L7.26		17.17.L9.26		350-360	9932.0091.C	Oil: SAE 7.5 / Air chamber: 140 MM / Spacer H=20
ZEPHYR 750	ZR750C/D	91>	◆◆	17.17.L7.26		17.17.L9.26		350-360	9932.0120.A	Oil: SAE 5 / Air chamber: 140 MM
ZEPHYR 1100	ZRT10A	92>	◆◆	17.17.M7.24		17.17.M9.24		348	9932.0145.B	Oil: SAE 7.5 / Air chamber: 140 MM / Spacer H=40
ZL 600	ZL600A	85-87							9932.0055.A	Oil: SAE 10 / Air chamber: 150 MM
ZL 900 / 1000 Eliminator		85>							9932.0055.M	Oil: SAE 10 / Air chamber: 150 MM / Spacer H=50
ZR-7	ZR750FF	99>			17.17.T8.28/01	17.17.T9.28/01	✓	317-327	9932.0263.A	Oil: SAE 15 / Air chamber: 140 MM
ZRX 400	ZRX400E	94>	◆◆	17.17.O7.32		17.17.O9.32		363-373	9932.0211.A	Oil: SAE 10 / Air chamber: 100 MM
ZRX 1100	ZRT10C	97-00	◆◆	17.17.R7.30		17.17.R9.30		357-367	9932.0199.B	Oil: SAE 7.5 / Air chamber: 165 MM / Spacer H=100
ZRX 1200	ZRT20	01>	◆◆	17.17.R7.30		17.17.R9.30		357-367	9932.0199.C	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=100
ZX-10	ZXT00B	88-03			17.17.I8.33/01	17.17.I9.33/01	✓	309-319	9932.0113.B	Oil: SAE 10 / Air chamber: 150 MM / Spacer H=15
ZX-6R Ninja	ZX600F	95-97			17.17.P8.37/01	17.17.P9.37/01	✓	320-330	9932.0225.A	Oil: SAE 5 / Air chamber: 130 MM
ZX-6R Ninja	ZX600	98-99		17.17.S7.39/01		17.17.S9.39/01	✓	336-346		
ZX-6R Ninja	ZX600JJ	00-02		17.17.U7.38/01		17.17.U9.38/01	✓	336-346	9932.0274.B	Oil: SAE 10 / Air chamber: 100 MM
ZX-6RR	ZX636B	03-04		17.17.X7.40		17.17.X9.40		330-340	9932.0295.A	Oil: SAE 5 / Air chamber: 135 MM / Spacer H=75
ZX-6RR		05-06		17.17.7A.60		17.17.9A.60	✓	323-333	9932.0199.E	Oil: SAE 10 / Air chamber: 115 MM
ZX-6RR		07		17.17.7C.66		17.17.9C.66		330-340	Q5 2008	
ZX-7 R Ninja	ZX750P	96>			17.17.Q8.41	17.17.Q9.41		351-361	9932.0249.A	Oil: SAE 10 / Air chamber: 105 MM
ZX-7 RR Ninja	ZX750N	96>			17.17.Q8.41	17.17.Q9.41		351-361	9932.0147.A	Oil: SAE 7.5 / Air chamber: 130 MM
ZX-9R Ninja	ZX900B	94-95			17.17.O8.42	17.17.O9.42		348-358	9932.0208.A	Oil: SAE 5 / Air chamber: 130 MM
ZX-9R Ninja	ZX900B	96-97			17.17.P8.44	17.17.P9.44		349-359	9932.0208.B	Oil: SAE 5 / Air chamber: 130 MM / Spacer H=75
ZX-9R Ninja	ZX900C1	98-99		17.17.S7.46		17.17.S9.46		329-339	9932.0253.A	Oil: SAE 10 / Air chamber: 135 MM
ZX-9R Ninja	ZX900EE	00-03		17.17.U7.45		17.17.U9.45		336-346	9932.0274.A	Oil: SAE 15 / Air chamber: 110 MM
ZX-10R	ZXT00C	04-05		17.17.Y7.61/01		17.17.Y9.61	✓	328-338	9932.0302.A	Oil SAE5 Air chamber:120 MM, vervangen 9932.0288.B
ZX-10R		06>							Q5 2008	
ZX-12 R	ZXT20A	00-01		17.17.U7.34		17.17.U9.34		337-347	9932.0266.A	Oil: SAE 20 / Air chamber: 105 MM
ZX-12 R		02>		17.17.W7.35		17.17.W9.35		337-347	9932.0266.B	Oil: SAE 10 / Air chamber: 95 MM / Spacer H=110
ZXR 400	ZX400L	91>			17.17.L8.47	17.17.L9.47		322-332	9932.0126.D	Oil: SAE 7.5 / Air chamber: 150 MM
ZXR 750	ZX750H1	89							9932.0230.D	Oil: SAE 5 / Air chamber: 140 MM / Spacer H=20
ZXR 750	ZX750H2	90							9932.0230.D	Oil: SAE 5 / Air chamber: 140 MM / Spacer H=20
ZXR 750 (UPSD 43 mm)	ZX750J	91-92			17.17.L8.49	17.17.L9.49		346-356	9932.0147.A	Oil: SAE 7.5 / Air chamber: 130 MM
ZXR 750 (UPSD 41 mm)	ZX750L	93-95			17.17.L8.49	17.17.L9.49		346-356	9932.0125.B	Oil: SAE 5 / Air chamber: 130 MM
ZXR 750 RR (UPSD 41 mm)	ZX750K/M	91-95			17.17.N8.50	17.17.N9.50		344-354	9932.0125.A	Oil: SAE 5 / Air chamber: 130 MM
ZZ-R 600	ZX600D	90-92			17.17.K8.57	17.17.K9.57		366-376	9932.0128.A	Oil: SAE 5 / Air chamber: 140 MM
ZZ-R 600	ZX600E	93>			17.17.N8.58/01	17.17.N9.58/01	✓	366-376	9602.0007.A	Oil: SAE 7.5 / Air chamber: 150 MM
ZZ-R 1100	ZXT10C	90-92			17.17.K8.51/01	17.17.K9.51/01	✓	313-323	9932.0230.H	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=70
ZZ-R 1100	ZXT10C	90-92			17.17.K8.51/01	17.17.K9.51/01	✓	313-323	9931.0012.A	Oil: SAE 10 Air chamber: 140 MM
ZZ-R 1100	ZXT10D	93-01			17.17.N8.53/01	17.17.N9.53/01	✓	339-349	9931.0016.A	Oil: SAE 7.5 / Air chamber: 120 MM
ZZ-R 1100	ZXT10D	93-01			17.17.N8.53/01	17.17.N9.53/01	✓	339-349	9932.0199.A	Oil: SAE 15 / Air chamber: 140 MM

ZZ-R 1200	ZXT20C	02>			17.17.W8.55/01	17.17.W9.55/01	✓	337-347	9932.0291.A	Oil: SAE 10 / Air chamber: 110 MM
ZZ-R 1400		07>			17.17.W8.56/01	17.17.W9.56/01	✓	324-334	9931.0041.A	Oil: SAE 5 Air chamber: 88 MM 563 CC
MOTO GUZZI										
T1-3	VD								9932.0153.A	Oil: Std / Air chamber: Std
T4, SP, Le Mans 2/3	VD/VG/VE/VF								9932.0153.B	Oil: Std / Air chamber: Std / Spacer H=25
T5, Le Mans 4/5	VR/VV								9932.0153.F	Oil: Std / Air chamber: Std / Spacer H=45
1000 SP ½	VH								9932.0153.G	Oil: Std / Air chamber: Std / Spacer H=45
California II	VT								9932.0153.C	Oil: Std / Air chamber: Std / Spacer H=10
California III	VW	88>							9932.0153.E	Oil: Std / Air chamber: Std / Spacer H=45
V1000 /G5/LM5									9932.0153.D	Oil: Std / Air chamber: Std / Spacer H=10
1100 SPORT / DAYTONA	KE/KL	94-95							9932.0163.B	Oil: SAE 15 / Air chamber: 140 MM
Quota 1000 (450 mm)	KM								9932.0130.I	Oil: SAE 15 / Air chamber: 180 MM / Spacer H=40
MZ / MuZ										
ETZ 250	ETZ250	83-92							9932.0013.G	Oil: SAE 15 / Air chamber: 160 MM
SKORPION 660	MUZ660	94>							9932.0137.C	Oil: SAE 15 / Air chamber: 160 MM
SUZUKI										
AN 400 BURGMAN	AU	98>			17.23.S8.03	17.23.S9.03		339-349	9931.0038.A	Oil: SAE 5 / Air chamber: 105 MM std+37mm
B-King 1300		07>			17.23.8D.01	17.23.9D.01		316-326		
DL 650 V-STROM	WVB1	04>		17.23.Y7.69/01		17.23.Y9.69/01	✓	336-346	9932.0260.D	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=10
DL 650 V-STROM lowered version	WVB1	04>		17.23.Y7.70/01		17.23.Y9.70/01	✓	317-327	9932.0260.D	Oil: SAE 10 / Air chamber: 140 MM / Spacer H=10
DL 1000 V-STORM	BS	02>		17.23.W7.05/01		17.23.W9.05/01	✓	341-351	9932.0260.B	Oil: SAE 10 Air chamber: 135 MM Spacer:20MM
DR 350 S	SK42B	89-94			17.23.K8.07	17.23.K9.07		437-447	9932.0150.A	Oil: SAE 7.5 / Air chamber: 160 MM
DR 350 S	SK42B	95>			17.23.P8.09	17.23.P9.09		437-447	9932.0150.A	Oil: SAE 7.5 / Air chamber: 160 MM
DR 650 R/RS	SP41/42/43B	90-92				17.23.K9.10		383-393	9932.0183.B	Oil: SAE 10 / Air chamber: 160 MM / Spacer H=20
DR 650 R/SE	SP43/44/45B	93-95				17.23.K9.10		383-393	9932.0183.A	Oil: SAE 10 / Air chamber: 160 MM
DR 650 SE	SP46B	96>			17.23.Q8.11	17.23.Q9.11		354-364		
DR 750 S	SR41B	88-90			17.23.I8.13/01	17.23.I9.13/01		409-419	9932.0161.A	Oil: SAE 7.5 / Air chamber: 160 MM
DR 800 S	SR42B	90			17.23.I8.13/01	17.23.I9.13/01	✓	409-419	9932.0161.A	Oil: SAE 7.5 / Air chamber: 160 MM
DR 800 S BIG	SR43B	91>			17.23.I8.13/01	17.23.I9.13/01	✓	409-419	9932.0167.B	Oil: SAE 7.5(2 bottles)Air chamber:160 MM Spacer H=20
GS 500		89-00							9932.0074.A	Oil: SAE 10 / Air chamber: 125 MM
GS 550 E	GS550AB	78-79							9932.0011.A	Oil: SAE 10 / Air chamber: 140 MM
GS 650 G Katana	GS650G	81>							9932.0008.D	Oil: SAE 10 / Air chamber: 130 MM
GS 750	GS750	78>	◆◆			17.23.A9.67		327-337	9932.0209.B	Oil: SAE 15 / Air chamber: 150 MM
GS 1000 E/S/H/L	GS1000	79-82	◆◆			17.23.A9.67		327-337	9932.0020.A	Oil: SAE 15 / Air chamber: 140 MM
GS 1100 L/G	GS1100	81>	◆◆			17.23.A9.67		327-337	9932.0212.B	Oil: SAE 15 / Air chamber: 140 MM / Spacer H=5
GSF 400 Bandit	GK75B	89>			17.23.L8.16	17.23.L9.16		305-315	9602.0005.A	Oil: SAE 5 / Air chamber: 135 MM
GSF 600 Bandit	GN77B	95-99			17.23.P8.18/01	17.23.P9.18/01	✓	298-308	9932.0229.A	Oil: SAE 15 / Air chamber: 160 MM
GSF 600 / S Bandit	WVA8	00-07			17.23.U8.20/01	17.23.U9.20/01	✓	313-322	9602.0020.B	Oil: SAE 15 Air chamber: 160 MM
GSF 650 / S Bandit		08		17.23.7D.21/01		17.23.9D.21/01	✓	311-321	9602.0020.D	

GSF 1200 Bandit	GV75A	96-00			17.23.P8.14/01	17.23.P9.14/01	✓	304-314	9932.0230.B	Oil: SAE 10 Air chamber: 160 MM
GSF 1200 / S Bandit	WVA9	01-07			17.23.V8.01/01	17.23.V9.01/01	✓	318-328	9932.0289.A	Oil: SAE 10 Air chamber: 100 MM
GSF 1250 / S Bandit		08			17.23.V8.02/01	17.23.V9.02/01	✓		9932.0281.B	
GSR 600	1B91	06>			17.23.7B.72/01	17.23.9B.72/01	✓	335-345	9932.0286.B	Oil: SAE 15 Air chamber: 120 MM
GSX 400 E/F	GS40X/F	80>							9932.0003.B	Oil: SAE 10 Air chamber: 140 MM Spacer H=45
GSX 400 Impulse	GK79A	94>	◆◆	17.23.O7.28		17.23.O9.28		316		
GSX 400 S Katana		92>	◆◆	17.23.M7.29		17.23.M9.29		358	9932.0171.A	Oil: SAE 15 Air chamber: 120 MM
GSX 600 F/Katana	GN72B	88-90			17.23.I8.31	17.23.I9.31/01	✓	298-308	9932.0136.A	Oil: SAE 7.5 Air chamber: 150 MM
GSX 600 F	GN72B	91-97			17.23.I8.31	17.23.I9.31/01	✓	298-308	9932.0126.B	Oil: SAE 7.5 Air chamber: 150 MM
GSX 600 F	AJ31	98>			17.23.S8.30	17.23.S9.30		298-308	9932.0257.B	Oil: SAE 5 Air chamber: 105 MM
GSX 750		00>	◆◆	17.23.U7.25		17.23.U9.25		323	9932.0238.B	Oil: SAE 10 Air chamber: 95 MM
GSX 750 S Katana	GR71A	79>	◆◆	17.23.H7.35		17.23.H9.35		333-343		
GSX 750 E	GS75X	80							9932.0003.F	Oil: SAE 10 Air chamber: 140 MM Spacer H=15
GSX 750 F	GR78A	89-97				17.23.J9.33		297-307	9932.0244.B	Oil: SAE 15 Air chamber: 150 MM Spacer H=25
GSX 750 F	AK11	98>			17.23.S8.34	17.23.S9.34		295-305	9932.0257.A	Oil: SAE 5 Air chamber: 105 MM
GSX 1100 F/Katana	GV72C	88				17.23.I9.22/01	✓	342-353	9932.0117.A	Oil: SAE 7.5 Air chamber: 150 MM
GSX 1100 F	GV72C	89-93				17.23.I9.22/01	✓	342-353	9932.0112.B	Oil: SAE 7.5 Air chamber: 150 MM
GSX 1100 F	GV72C	94>				17.23.I9.22/01	✓	342-353	9932.0231.A	Oil: SAE 5 Air chamber: 170 MM
GSX 1100 G	GV74A	91>			17.23.K8.23	17.23.K9.23		298-308	9932.0143.B	Oil: SAE 15 Air chamber: 160 MM
GSX 1100 S Katana	GS1100X	80-85	◆◆						9932.0032.A	Oil: SAE 10 Air chamber: 140 MM
GSX 1200	IA31	00>	◆◆	17.23.U7.25		17.23.U9.25		323	9932.0238.B	Oil: SAE 10 Air chamber: 95 MM
GSX 1300 R Hayabusa	A11	99-07		17.23.T7.26/01		17.23.T9.26/01	✓	324-334	9932.0264.A	Oil: SAE 10 Air chamber: 100 MM
GSX 1300 R Hayabusa		08>		17.23.7D.28/01		17.23.9D.28/01		327-337	9931.0034.A	Oil: SAE 10 Air chamber: 100 MM
GSX 1400	WVBN	02>	◆◆	17.23.W7.27		17.23.W9.27		330-340	9932.0290.A	Oil: SAE 7.5 Air chamber: 120 MM
GSX-R 400		91>							9602.0003.A	Oil: SAE 10 Air chamber: 130 MM
GSX-R 600 V	AD	97-00			17.23.R8.44/01	17.23.R9.44/01	✓	348-358	9932.0258.A	Oil: SAE 5 Air chamber: 135 MM
GSX-R 600 V Comp	AD	97-99							9931.0019.A	Oil:5 SAE Air chamber:135 MM
GSX-R 600	BG	01-03		17.23.V7.43/01		17.23.V9.43	✓	326-336		
GSX-R 600	WVB2/B3	04-05		17.23.Y7.64		17.23.Y9.64		327-337	9932.0303.A	Oil: SAE 5 Air chamber: 155 MM
GSX-R 600	CE11/CF11	06-07		17.23.7B.71/01		17.23.9B.71	✓	314-324	9932.0254.D	Oil: SAE 5 Air chamber: 120 MM Spacer=20 MM
GSX-R 600 / 750		08		17.23.7D.76/01		17.23.9D.76		311-321	9932.0299.A	Oil: SAE5 Air chamber:140 MM
GSX-R 750 F	GR75A	85-87			17.23.F8.47	17.23.F9.47		294	9932.0112.A	Oil: SAE 7.5 Air chamber: 150 MM
GSX-R 750 J	GR77B	88-89			17.23.I8.48	17.23.I9.48		306-316	9932.0143.A	Oil: SAE 5 Air chamber: 150 MM
GSX-R 750 L (41 mm UPSD)	GR7AB/BB	90-93			17.23.K8.49/01	17.23.K9.49/01	✓	313-323	9932.0229.B	Oil: SAE 5 Air chamber: 110 MM Spacer H=5
GSX-R 750 W (43 mm UPSD)	GR7BB	94-95			17.23.K8.49/01	17.23.K9.49/01	✓	313-323	9932.0207.A	Oil: SAE 7.5 Air chamber: 100 MM
GSX-R 750 T (43 mm UPSD)	GR7DB	96-99		17.23.Q7.51/01	17.23.Q8.51/01	17.23.Q9.51/01	✓	352-362	9932.0232.A	Oil: SAE 20 Air chamber: 100 MM
GSX-R 750 T RACE	GR7DB	96-99							9932.0234.A	Oil: SAE 15 Air chamber: 100 MM
GSX-R 750	BD	00-03		17.23.U7.45/01		17.23.U9.45/01	✓	326-336	9932.0267.A	Oil: SAE 20 Air chamber: 95 MM
GSX-R 750	WVB2/B3	04-05		17.23.Y7.64		17.23.Y9.64		327-337	9932.0303.A	Oil: SAE 5 Air chamber: 155 MM

GSX-R 750	CE11/CF11	06-07		17.23.7B.71/01		17.23.9B.71	✓	314-324	9932.0254.D	Oil: SAE 5 Air chamber: 120 MM Spacer=20 MM
GSX-R 750		08		17.23.7D.76/01		17.23.9D.76	✓	311-321	9932.0299.A	Oil: SAE5 Air chamber:140 MM
GSX-R 1000	WVBL	01-02		17.23.V7.36/01		17.23.V9.36	✓	331-341	9932.0287.A	Oil: SAE 5 Air chamber: 95 MM
GSX-R 1000	WVBZ	03-04		17.23.V7.36/01		17.23.V9.36	✓	331-341	9932.0298.A	Oil: SAE 5 Air chamber: 90 MM
GSX-R 1000		05-06		17.23.7A.65/01		17.23.9A.65/01	✓	321-331	9932.0298.A	Oil: SAE 5 Air chamber: 90 MM
GSX-R 1000		08>		17.23.7C.73		17.23.9C.73		311-321		
GSX-R 1100 G		86-88			17.23.G8.37/01	17.23.G9.37/01	✓	316-326		
GSX-R 1100 K (43 mm)	GV73C	89			17.G28823.J8.39	17.23.J9.39		314-324	9932.0143.D	Oil: SAE 5 Air chamber: 125 MM
GSX-R 1100 L (41 mm UPSD)	GV73C	90-92			17.23.K8.41/01	17.23.K9.41	✓	314-324	9602.0008.A	Oil: SAE 5 Air chamber: 130 MM Spacer: 10 mm
GSX-R 1100 W	GU75C	93-94			17.23.P8.42/01	17.23.P9.42/01	✓	314-324	9932.0182.A	Oil: SAE 5 Air chamber: 110 MM
GSX-R 1100 W	GU75C	95>			17.23.P8.42/01	17.23.P9.42/01	✓	314-324	9932.0227.A	Oil: SAE 5 Air chamber: 130 MM
LS 650 Savage	NP41B	91>							9932.0092.B	Oil: SAE 7.5 Air chamber: 150 MM Spacer H=10
RF 600 R	GN76B	93>							9932.0187.D	Oil: SAE 7.5 Air chamber: 140 MM Spacer H=75
RF 600 R Comp.	GN76B	93>							9932.0187.E	Oil: SAE 7.5 Air chamber: 140 MM Spacer H=75
RF 900 R	GT73B	94-95							9932.0249.B	Oil: SAE 5 Air chamber: 160 MM
RG 500 RF Gamma	HM31A	85>				17.23.F9.53		317-327	9932.0090.B	Oil: SAE 20 Air chamber: 130 MM
RGV 250 Gamma	VJ21A	89-90							9932.0139.C	Oil: SAE 5 Air chamber: 125 MM Spacer H=10
RGV 250 Gamma	VJ22B	91			17.23.N8.54	17.23.N9.54		307-317	9932.0126.E	Oil: SAE 15 Air chamber: 130 MM Spacer H=10
RGV 250 Gamma	VJ22B	92>			17.23.N8.54	17.23.N9.54		307-317	9932.0187.B	Oil: SAE 15 Air chamber: 130 MM
SV 650 (S)	AV	99-02			17.23.T8.56	17.23.T9.56		337-347	9932.0261.A	Oil: SAE 20 Air chamber: 125 MM Spacer H=25
SV 650 (S)		03>		17.23.Y7.63		17.23.Y9.63		331-341	9932.0231.A	Oil: SAE 5 Air chamber: 170 MM
SV 1000	BX	03>			17.23.X8.62/01	17.23.X9.62/01	✓	328-338	9932.0245.C	Oil: SAE 10 (2 bottles) Air chamber: 110 MM Spacer 150mm
TL 1000 S (includes level part)	AG	97>			17.23.R8.59	17.23.R9.59		247	9932.0269.B	Oil: SAE 15 Air chamber: 100mm Spacer H=35
TL 1000 R (includes level part)	AM	98>			17.23.T8.58	17.23.T9.58		255	9932.0269.A	Oil: SAE 15 Air chamber: 100mm
VS 600 GL Intruder	VN51B	95>							9932.0162.D	Oil: SAE 10 Air chamber: 170 MM
VS 750 GL Intruder	VR51BD	85>							9932.0162.B	Oil: SAE 7.5 Air chamber: 170 MM
VS 800 GL Intruder	V552B	92>							9932.0162.B	Oil: SAE 7.5 Air chamber: 170 MM
VS 1400 GL Intruder	VX51L	87>	◆◆						9932.0097.B	Oil: SAE 15 Air chamber: 150 MM
VS 1500 Intruder LC			◆◆						9932.0117.C	Oil : SAE 10 Air chamber: 170 MM Spacer: 20 MM
VX 800	V551B	90>							9932.0162.C	Oil: SAE 10 Air chamber: 170 MM
XF 650 Freewind	AC	97>			17.23.R8.60	17.23.R9.60		338-348	9932.0255.A	Oil: SAE 10 Air chamber: 170 MM
TRIUMPH										
Daytona 900/1200	T300D	91>			17.28.O8.02	17.28.O9.02		317-327	9932.0230.E	Oil : SAE 10 Air chamber: 140 MM Spacer 10 mm
Daytona Super IIII	TC310	94>			17.28.O8.02	17.28.O9.02		317-328	9932.0230.F	Oil: SAE 10 Air chamber: 140 MM Spacer H=10
Daytona T595	T595	97-00						369-379	9932.0245.A	Oil: SAE 7.5 Air chamber: 100 MM
Daytona 675	TMD1	06>			17.28.7B.23/01	17.28.9B.23	✓	290-300	9932.0306.A	Oil: SAE 5 Air chamber: 105 MM
Street Triple 675		07>			17.28.7D.25/01	17.28.9D.25/01	✓	285-295	9931.0045.A	Oil: SAE 5 Air chamber: 115 MM
Speed Triple	T300B/C	94>			17.28.O8.02	17.28.O9.02		317-327	9932.0230.G	Oil: SAE 10 Air chamber: 140 MM Spacer H=10
Speed Triple T509	T509	97>			17.28.R8.05	17.28.R9.05		369-379	9932.0245.B	Oil: SAE 7.5 Air chamber: 100 MM

Speed Triple 955i		97-04						9932.0245.D	Oil: SAE 7.5 Air chamber: 100 MM
Speed Triple 955i	515 NJ	05-06		17.28.7A.24/01		17.28.9A.24/01	✓	370-380 9932.0313.A	Oil: SAE 7.5 Air chamber:135 MM
Speed Triple (1050)		07>						Q2 2009	
Sprint 900	T300A	95>		17.28.O8.02		17.28.O9.02		317-327 9932.0130.J	Oil: SAE 10 Air chamber: 160 MM
Sprint RS	TF605	00>		17.28.U8.06/01		17.28.U9.06	✓	363-373 9932.0275.A	Oil: SAE 15 Air chamber: 110 MM
Sprint ST	TF600	99>		17.28.T8.08/01		17.28.T9.08/01	✓	351 9932.0259.B	Oil: SAE 7.5 Air chamber: 140 MM Spacer H=35
Thruxton 900		04>	◆◆	17.28.Y7.22		17.28.Y9.22		372-382 -	
Thunderbird	T309RT	95>		17.28.P8.14/01		17.28.P9.14/01	✓	337-347 9932.0130.E	Oil: SAE 10 Air chamber: 170 MM
Thunderbird Sport		99>		17.28.T8.13		17.28.T9.13		346-356 -	
Tiger	T400	93-98		17.28.M8.16		17.28.M9.16		363-373 9932.0146.B	Oil: SAE 15(2 bottles)Air chamber: 180 MM
Tiger 900	TTG7	99-00						9932.0277.A	Oil: SAE 15 Air chamber: 120 MM
Tiger 955i	T572	01-04						9932.0278.A	Oil: SAE 15 Air chamber: 120 MM
Tiger 1050i		07>		17.28.8C.18		17.28.9C.18		Q2 2009	
Trident 750/900	T300	92>		17.28.O8.02		17.28.O9.02		317-327 9932.0130.B	Oil: SAE 10 Air chamber: 180 MM
Trophy 900	T300E	92>		17.28.O8.02		17.28.O9.02		317-327 9932.0130.C	Oil: SAE 10 Air chamber: 180 MM
TT 600	TH800	00>		17.28.U8.21/01		17.28.U9.21/01	✓	313-323 9932.0281.A	Oil: SAE 15 Air chamber:140 MM Spacer:25
Trophy 1200	T300E	92>		17.28.O8.02		17.28.O9.02		317-327 9932.0230.I	Oil: SAE 7.5 Air chamber: 180 MM Spacer H=70
YAMAHA									
BT 1100 Bulldog	RP05	01>						9932.0143.E	Oil: SAE 10 Air chamber: 150 MM
FJ 1100	47E	84-87				17.27.F9.04/01	✓	288-298 9932.0106.B	Oil: SAE 15 Air chamber: 170 MM
FJ 1200	1XJ	85-87				17.27.F9.04/01	✓	288-298 9932.0106.C	Oil: SAE 15 Air chamber: 170 MM
FJ 1200	3CW	88-90		17.27.J8.05/01		17.27.J9.05/01		286-296 9932.0106.D	Oil: SAE 7.5 Air chamber: 150 MM
FJ 1200	3YA/3XW	91>		17.27.L8.07/01		17.27.L9.07/01	✓	301-311 9932.0105.B	Oil: SAE 7.5 Air chamber: 150 MM Spacer H=65
FJR 1300	3YARP	01>		17.27.V7.09/01		17.27.V9.09/01	✓	323-333 9932.0273.A	Oil: SAE 5 (2 bottles)Air chamber: 100 MM Spacer H=3
FJR 1300 ABS		03>		17.27.X7.77/01		17.27.X9.77/01	✓	323-333 9932.0273.A	Oil: SAE 5 (2 bottles)Air chamber: 100 MM Spacer H=3
FZ 1 / FZ 1 FAZER		<05		17.27.7B.92/01		17.27.9B.92/01	✓		
FZ 1 / FZ 1 FAZER	RN16	06>		17.27.8B.92/01		17.27.9B.92/01	✓	317-327 9932.0287.B	Oil: SAE 10 Air chamber: 100 MM
FZ 6	RJ07	04>		17.27.Y8.78/01		17.27.Y9.78/01	✓	301-311 9932.0295.B	Oil: SAE 10 Air chamber: 115 MM Spacer 210 mm
FZ 6 Fazer	RJ07	04>		17.27.Y8.78/01		17.27.Y9.78/01	✓	301-311 9932.0295.B	Oil: SAE 10 Air chamber: 115 MM Spacer 210 mm
FZ 6 Fazer S2		07>		17.27.8D.79/01		17.27.9D.79/01		9932.0271.B	
FZ 750	1FN	85-86				17.27.F9.11		291-301 9932.0092.A	Oil: SAE 10 Air chamber: 140 MM
FZ 750 GEN	2KK	87>				17.27.H9.12		301-311 9932.0093.A	Oil: SAE 10 Air chamber: 140 MM
FZR 400/600 GEN	3RH/RG/HE	88-90						9932.0093.C	Oil: SAE 10 Air chamber: 150 MM Spacer H=20
FZR 600 GEN	3HHEO	91-93				17.27.L9.17		298-308 9932.0093.C	Oil: SAE 10 Air chamber: 150 MM Spacer H=20
FZR 1000 GEN	2LA	86-88						9932.0220.D	Oil: SAE 7.5 Air chamber: 150 MM Spacer H=30
FZR 600 R	4MH/JH	94				17.27.O9.18		365-374 9932.0202.A	Oil: SAE 10 Air chamber: 170 MM
FZR 600 R	4MH/JH	95>				17.27.O9.18		365-374 9932.0139.B	Oil: SAE 10 Air chamber: 170 MM
FZR 750 R (OW01)	3PJ	89-92						9932.0220.E	Oil: SAE 7.5 Air chamber: 150 MM Spacer H=30
FZR 1000 EXUP	3LE	89-90		17.27.L8.13/01		17.27.L9.13/01	✓	341-351 9932.0145.A	Oil: SAE 7.5 Air chamber: 140 MM

FZR 1000 EXUP	3LE	91-93			17.27.L8.13/01	17.27.L9.13/01	✓	341-351	9932.0163.A	Oil: SAE 7.5 Air chamber: 130 MM
FZR 1000 EXUP	3LE	94>			17.27.L8.13/01	17.27.L9.13/01	✓	341-351	9932.0226.A	Oil: SAE 7.5 Air chamber: 130 MM
FZR 1000 GEN	2LA	86-88			17.27.H8.15	17.27.H9.15		301-311	9932.0116.C	Replaced by: 9932.0220.D
FZS 600 FAZER	RJ	98-03			17.27.S8.22	17.27.S9.22		304-314	9932.0250.B	Oil: SAE 10 Air chamber: 155 MM Spacer H=95
FZS 600 S FAZER	RJ	00-03			17.27.S8.22	17.27.S9.22		304-314	9932.0250.C	Oil: SAE 15 Air chamber: 155 MM Spacer H=75
FZS 1000 S FAZER / GT	RN061	01-05		17.27.V7.19/01		17.27.V9.19/01	✓	303-313	9932.0271.A	Oil: SAE 5 Air chamber: 130 MM
FZX 750 FAZER	2JE	86>	◆◆						9932.0055.H	Oil: SAE 10 Air chamber: 150 MM Spacer H=50
MT-01									Q1 2009	
MT-03	RM021	06>		17.27.7B.91/01		17.27.9B.91/01	✓	358-368	9932.0295.C	Oil: SAE 15 Air chamber: 125 MM Spacer 100 mm
R1-Z		90>							9932.0090.D	Oil: SAE 10 Air chamber: 140 MM Spacer H=10
RADIAN 600		86>							9932.0055.D	Oil: SAE 15 Air chamber: 135 MM Spacer H=25
RD 250/350 LC	4L1/4L0	80-82			17.27.A8.25	17.27.A9.25		317-327	9932.0003.C	Oil : SAE 10 Air chamber: 140 MM Spacer: 45 MM
RD 250/350 YPVS	31K	83-85							9932.0020.B	Oil: SAE 10 Air chamber: 150 MM Spacer H=35
RD 500 LC	47X/1GE	84>			17.25.E8.27	17.25.E9.27		288-298	9932.0055.E	Oil: SAE 15 Air chamber: 170 MM Spacer H=45
SR 400	2J2	77>	◆◆	17.27.B7.28		17.27.B9.28		318-328	9932.0006.A	Oil: SAE 15 Air chamber: 150 MM
SR 500	48T	78>	◆◆	17.27.B7.28		17.27.B9.28		318-328	9932.0006.A	Oil: SAE 15 Air chamber: 150 MM
SRX 400		85-89	◆◆	17.27.G7.31		17.27.G9.31		299	9932.0048.A	Oil: SAE 5 Air chamber: 140 MM
SRX 400		90>			17.27.K8.32	17.27.K9.32		292-302	9932.0087.A	Oil: SAE 15 Air chamber: 110 MM
SRX 600	1XM/XL	85-89	◆◆	17.27.G7.31		17.27.G9.31		299	9932.0048.B	Oil: SAE 5 Air chamber: 140 MM
SRX 600		90>			17.27.K8.32	17.27.K9.32		292-302	9932.0087.B	Oil: SAE 15 Air chamber: 110 MM
SZR 660 (4SU)	4SU	96>			17.27.Q8.34	17.27.Q9.34		314-324	9932.0243.A	Oil: SAE 5 Air chamber: 160 MM
TDM 850	3VD/4CM	91-95		17.27.L7.36		17.27.L9.36		308-318	9932.0128.B	Oil: SAE 7.5 Air chamber: 150 MM Spacer H=15
TDM 850	4TX	96>		17.27.Q7.38		17.27.Q9.38		308-318	9932.0241.A	Oil: SAE 7.5 Air chamber: 135 MM
TDM 900	JYARN	02-03		17.27.W7.40/01		17.27.W9.40/01	✓	324-334	9932.0283.A	Oil: SAE 15 Air chamber: 120 MM
TDM 900 (also ABS)	JYARN	04>		17.27.W7.40/01		17.27.W9.40/01	✓	324-334	9932.0283.B	Oil: SAE 15 Air chamber: 120 MM Spacer 165 MM
TDR 250	3CK	88>							9932.0089.A	Oil: SAE 10 Air chamber: 140 MM
TRX 850	4UN	96>		17.27.P8.42/01		17.27.P9.42/01	✓	351-361	9602.0020.A	Oil: SAE 10 Air chamber: 150 MM
TT 350		86-93							9931.0008.A	Oil: SAE 7.5 Air chamber: 150 MM
TT 600	4LW	85-89							9931.0010.A	Oil: SAE 7.5 Air chamber: 180 MM
TT 600 ADJ.L.		93-97		17.27.N8.44		17.27.N9.44		395-405	9932.0218.A	Oil: SAE 7.5 Air chamber: 120 MM
TT 600 R		98>		17.27.S8.45		17.27.S9.45		399-409	9932.0268.A	Oil: SAE 15 Air chamber: 185 MM Spacer H=25
TR-1 1000		81>				17.27.D9.81		378-383		
TZR 250	2MA	85-87							9932.0101.A	Oil: SAE 10 Air chamber: 150 MM
TZR 250	2MA	88>		17.27.I8.46		17.27.I9.46		268-278	9932.0101.A	Oil: SAE 10 Air chamber: 150 MM
V-MAX 1200	2EN	86-92	◆◆	17.27.G7.47		17.27.G9.47		329-339	9932.0204.A	Oil: SAE 7,5 Air chamber: 160 MM
V-MAX 1200	2EN/2WE	93>	◆◆	17.27.G7.47		17.27.G9.47		329-339	9932.0143.C	Oil: SAE 10(2 bottles)Air chamber: 170 MM
XJ 550	4V8	81>							9932.0037.B	Oil: SAE 10 Air chamber: 160 MM
XJ 600	51J/3KN/KM	84>							9932.0055.B	Oil: SAE 15 Air chamber: 160 MM
XJ 600 S Diversion	4LX/4BR	91-97				17.27.S9.49		273-283	9932.0090.C	Oil: SAE 7.5 Air chamber: 150 MM Spacer H=10

XJ 600 S Diversion (D=41)	RJ01	98>			17.27.S9.49		273-283	9932.0252.B	Oil: SAE 7.5 Air chamber: 150 MM Spacer 25 mm	
XJ 650	4KO	80>	◆◆					9932.0023.C	Oil: SAE 15 Air chamber: 160 MM	
XJ 650 Maxim								9932.0020.D	Oil: SAE 15 Air chamber: 160 MM	
XJ 750/F (41Y)	41Y	84>						9932.0055.G	Oil: SAE 10 Air chamber: 150 MM Spacer H=50	
XJ 750 Maxim		85						9932.0055.O	Oil: SAE 15 Air chamber: 160 MM Spacer H=10	
XJ 750/R	11M	82-83						9932.0048.E	Oil: SAE 10 Air chamber: 140 MM Spacer H=10	
XJ 900 (ANTIDIVE)	31A	83-84						9932.0013.F	Oil: SAE 15 Air chamber: 140 MM	
XJ 900 F (NO ANTIDIVE)	58L	85>						9932.0046.F	Oil: SAE 15 Air chamber: 140 MM Spacer H=5	
XJ 900 S DIVERSION	4KM	95			17.27.P8.50/01	17.27.P9.50/01	✓	303-313	9932.0220.A	Oil: SAE 10 Air chamber: 170 MM
XJ 900 S DIVERSION	4KM	96>			17.27.Q8.52/01	17.27.Q9.52	✓	303-313	9932.0220.H	Oil: SAE 10 Air chamber: 170 MM Spacer H=40
XJR 400		93>	◆◆	17.27.N7.55		17.27.N9.55		320	9932.0196.A	Oil: SAE 7.5 Air chamber: 150 MM
XJR 400 R		95>	◆◆						9932.0136.B	Oil: SAE 7.5 Air chamber: 150 MM
XJR 1200	4PU	94-98	◆◆	17.27.O7.53		17.27.O9.53		330-340	9932.0292.B	Replaced by: 9932.0297.C
XJR 1200 SP	4PU	96>	◆◆	17.27.O7.53		17.27.O9.53		330-340	9932.0230.J	Oil: SAE 10 Air chamber: 160 MM Spacer H=40
XJR 1200 SP (K.R. Replica)	4PU	97-98	◆◆	17.27.O7.53		17.27.O9.53		330-340		
XJR 1300	RP02	99-01	◆◆	17.27.O7.53		17.27.O9.53		330-340	9932.0297.C	Oil: SAE 10 Air chamber: 160 MM Spacer H=90
XJR 1300 / SP	RP06	02-03	◆◆	17.27.V7.77		17.27.V9.77		323-333	9932.0297.A	Oil: SAE 15 Air chamber: 130 MM
XS 650 /SE	447/3L1	77>							9932.0006.C	Oil: SAE 15 Air chamber: 150 MM
XS 750 (1T5)	1T5	79>							9932.0032.B	Oil: SAE 15 Air chamber: 160 MM
XS 400 SE	4G5	80-81							9932.0003.E	Oil: SAE 10 Air chamber: 140 MM
XS 1100	2H9	78-80	◆◆						9932.0212.E	Oil: SAE 10 Air chamber: 160 MM Spacer H=10
XT 350	1WM/55V/3YT	85>							9932.0060.A	Oil: SAE 10 Air chamber: 160 MM
XT 500	1U6	76>	◆◆			17.27.C9.86		367-377	9931.0002.A	Oil: SAE 10 Air chamber: 180 MM
XT 550	5Y3	82>							9931.0004.A	Oil: SAE 10 Air chamber: 180 MM
XT 600	43F	84>				17.27.D9.56		394-404		
XT 600 E/K	3TB/UW	90-99			17.27.K8.57	17.27.K9.57		277-287	9932.0149.A	Oil: SAE 10 Air chamber: 180 MM
XT 600 E	AD	00>				17.27.K9.57		277-287	9932.0149.A	Oil: SAE 10 Air chamber: 180 MM
XT 600	34L/55W	84-85				17.27.D9.59/01	✓	395-405	9931.0007.A	Oil: SAE 7.5 Air chamber: 180 MM
XT 600 TEN.	34L/55W	84-85				17.27.D9.59/01	✓	395-405	9931.0007.A	Oil: SAE 7.5 Air chamber: 180 MM
XT 600 Z/TENERE	1VJ	85-87							9932.0122.A	Oil: SAE 7.5 Air chamber: 180 MM
XT 600 Z/TENERE	3AJ	88>				17.27.D9.59/01	✓	395-405	9932.0133.A	Oil: SAE 7.5 Air chamber: 180 MM
XTZ 660	4MD/3YF	91-94			17.27.L8.60	17.27.L9.60		321-331	9932.0167.A	Oil: SAE 7.5(2 bottles)Air chamber:160 MM
XT 660 R		04>				17.27.Y9.82		337-347	9932.0167.D	Oil: SAE 10 Air chamber:160 MM
XT 660 X		04>				17.27.Y9.82		337-347	9932.0310.A	Oil: SAE 10 Air chamber:150 MM
XT 660 Z Tenere		08>			not possible	not possible			9932.0310.B	
XTZ 750 SUPER TENERE	3LD/WM	89>			17.27.I8.62	17.27.I9.62		455-465	9932.0146.A	Oil: SAE 15(2 bottles)Air chamber: 180 MM
XV 1100 VIRAGO	JYA1TE	86>							9932.0048.C	Oil: SAE 10 Air chamber: 190 MM
XV 535	2YL/3BR	89>							9932.0020.C	Oil: SAE 10 Air chamber: 150 MM Spacer H=50
XV 750	5G5	81							9932.0175.B	Oil: SAE 15 Air chamber: 150 MM

XV 920	2GH	84>						9932.0023.D	Oil: SAE 15 Air chamber: 140 MM Spacer H=5
XVF 1100 Dragstar		99>						9932.0126.I	Oil: SAE 15 Air chamber: 160 MM
XVZ 1200 Venture								9932.0192.D	Oil: SAE 10 Air chamber: 140 MM
XVZ 1300 Royal								9932.0192.D	Oil: SAE 10 Air chamber: 140 MM
YZF 1000 R TH.ACE	4VD/4SV	96>		17.27.Q8.64	17.27.Q9.64		341-351	9932.0247.A	Oil: SAE 10 Air chamber: 110mm
YZF 600 THUNDERCAT	4TV/WD	96>		17.27.Q8.69	17.27.Q9.69		360-370	9932.0243.B	Oil: SAE 10 Air chamber: 140 MM Spacer H=30
YZF 600 R6	RJ031	99-00		17.27.T7.73/01	17.27.T9.73	✓	292-302	9932.0254.B	Oil: SAE 7.5 Air chamber: 100MM
YZF 600 R6	RJ031	01-02		17.27.U7.71	17.27.U9.71		300-310	9932.0293.A	Oil: SAE 10 Air chamber: 115 MM
YZF 600 R6	RJ051	03-04		17.27.X7.72/01	17.27.X9.72/01	✓	292-302	9932.0293.A	Oil: SAE 10 Air chamber: 115 MM
YZF 600 R6		05		17.27.7A.80/01	17.27.9A.80/01	✓	292-302	9932.0304.A	
YZF 600 R6	RJ11	06-07		17.27.7B.88/01	17.27.9B.88/01	✓	289-299		
YZF 600 R6		08						Q5 2008	
YZF 750 R	4HN	93>		17.27.N8.75	17.27.N9.75		340-350	9602.0006.B	Oil: SAE 7.5 Air chamber: 130 MM
YZF 750 SP R-LINK	4HT	93>		17.27.N8.76	17.27.N9.76		340-350	9602.0006.B	Oil: SAE 7.5 Air chamber: 130 MM
YZF 1000 R1	RN01	98-99		17.27.S7.68	17.27.S9.68		298-308	9932.0254.A	Oil: SAE 7.5 Air chamber: 95 MM
YZF 1000 R1	RN04	00-01		17.27.U7.66	17.27.U9.66		295-305	9932.0254.C	Oil: SAE 20 Air chamber: 95 MM
YZF 1000 R1	RN09	02-03		17.27.W7.67	17.27.W9.67		296-306	9932.0288.A	Oil: SAE 5 Air chamber: 85 MM
YZF 1000 R1	RN12	04-06		17.27.Y7.79	17.27.Y9.79		298-308	9932.0306.B	Oil: SAE 5 Air chamber: 100 MM
YZF 1000 R1		07>						Q5 2008	